



QUICK-FIT INSTALLATION GUIDE

REAR WHEEL RUBBISH BIN



Part No: **RWRS**



MSA4X4.COM.AU | GEAR FOR LIFE

CONGRATULATIONS ON YOUR PURCHASE OF AN MSA 4X4 QUALITY REAR WHEEL RUBBISH BIN



FITTING INSTRUCTIONS

1. Hold Bag against spare wheel and position straps behind. The straps cross over (See diagram on opposite page), and attach underneath the wheel mount to the diagonal clip.
2. Ensure bag is placed right at the top of spare wheel and firmly tension straps.
3. When both straps are tensioned, feed strap back through safety tri-slide clip.



MSA 4X4 Accessories does not recommend carrying fuel and/or water jerry cans in this product.



**Designed and Manufactured by
MSA 4X4 Accessories Pty Ltd**

43 Harrington Street
Arundel, QLD 4214 Australia
Phone: (07) 5594 6664

www.msa4x4.com.au

ABN: 50 150 429 566



**Please refer to our website
for lifetime guarantee full
terms and conditions.**